

For your safety, please read the following before using.


- Do not use corrosive or flammable gas or liquid with this product.
- Please use within the rating pressure range. Do not apply pressure beyond recommended maximum withstand pressure, permanent damage to the pressure sensor may occur.
- Do not drop, hit or allow excessive shock. Even if switch body appears undamaged, internal components may be broken and can cause malfunction.
- Turn power off before connecting wiring. Wrong wiring or short circuit will damage and / or cause malfunction.
- Do not use in environment containing steam or oil vapor.
- This product is not explosion-proof rated. Do not use in atmosphere containing flammable or explosive gases.
- Wiring for pressure sensor should avoid power source line and high voltage line. If use in the same circuit, noise may cause malfunction.

A. SPECIFICATIONS

TYPE	MP43P-□ (Positive)	MP43V-□ (1 Value only)	MP43D-□ (Continuous)
Rated pressure range	0.000~1.000MPa	0.0~101.0kPa	0.000~100.0kPa
Setting pressure range	<0.000~1.000MPa	0.0~101.0kPa	<0.0~100.0kPa
Withstand pressure	1.5MPa	200kPa	
Fluid	Filtered air, Non-corrosive (Non-flammable) gas		
	kPa	—	0.1
	MPa	0.001	—
	kg/cm ²	0.01	0.001
	bar	0.01	0.001
	psi	0.1	0.01
	inHg	—	0.1
	mmHg	—	1
Power supply voltage	12 to 24V DC (15% ripple, (P-P) 10% or less)		
Current consumption	≤40mA (When no output)		
Switch output	NPN open collector 2 outputs Max. load current: 250mA Max. supply voltage: 30V DC Residual voltage: 1.5V	PNP open collector 2 outputs Max. load current: 120mA Max. supply voltage: 24V DC Residual voltage: 1.5V	
Repeatability (Switch output)	±0.2% F.S. at 1st digit		
On/Off delay	—		
Hysteresis	Adjustable (1%)		
Response time	1.2ms (chattering-proof function: 25ms, 100ms, 250ms, 500ms, 1000ms and 1500ms selectable)		
Output short-circuit protection	Yes		
7 segment LCD display	Two color (Red/Green) main and sub display, One line 5-digit display		
Indicator accuracy	±2% F.S. at 1st digit, at 25°C (reference temperature: 25°C)		
Switch ON Indicator	Orange LED indicator (OUT1/OUT2)		
Analogue output (Voltage Output) *2	Output Voltage: 1 to 5V (F.S. 5V) Linearity: ±1% F.S. Output impedance: about 1kΩ Output current: 4mA (24V DC power supply) Linearity: ±1% F.S. Max. Load Impedance: 300Ω (24V DC power supply) Max. Load Impedance: 150Ω		
Analogue output (Current Output) *3	Output Current: 4mA (24V DC power supply) Linearity: ±1% F.S. Max. Load Impedance: 300Ω (24V DC power supply) Max. Load Impedance: 150Ω		
Isolation	IP67		
Operating temp. range	Operation: 0~55°C, Storage: -10~60°C (No condensation at 25°C)		
Storage temp. range	Operation/Storage: 0~55°C (No condensation at 25°C)		
Humidity	100% RH (No condensation at 25°C)		
Shock	SMD (at 100V DC, between case and lead wire)		
Vibration	Total amplitude 1.0mm at 100, 1000, 10000 Hz (for 1 minute, two hours each in direction of X, Y and Z)		
Temperature characteristic	±2.5% F.S. of detected pressure (25°C at temp. range of 0~55°C)		
Port size	F1: R1/8", M5, F2: NPT1/8", F3: G1/8" (BSPP), M5		
Lead wire	26 (resistance outside 150cm)		
Weight	Approx. 45g (with 2 meter lead wire)		

*1. Hysteresis value is adjustable within 1~5 digits for one point set mode and window comparator mode.
*2. If analog current output is selected, the analog current output cannot be selected at the same time.
*3. If analog voltage output is selected, the analog voltage output cannot be selected at the same time.


H. ADVANCE SETTING MODE



[NOTE:]
1. When setting is [ON], the power-save mode would be started.
2. When setting is [ON], the display copy function would be started.
3. When setting is [ON], the display fine adjustment mode would be started.
Please refer the item [G] in detailed.


I. POWER-SAVE MODE

- During Power-Save mode, the main display will be turned off if no buttons is pressed after 30 seconds.
- During Power-Save mode, the output LCD may not be synchronize with the output. It is normal and will not affect output operation.
- Press any button to turn-on main display temporarily.



[NOTE:]
Main display is off, sub-display will flash "P".

B. OUTPUT CIRCUIT WIRING DIAGRAMS



C. ORDERING INFORMATION

MP43C-010-F1


Pressure Range
C: Compound (-101.0~101.0kPa)
V: Vacuum (0.0~101.0kPa)
P: Positive (0.0~100.0MPa)

Output Specifications
010: 2 NPN+Analog (Voltage) output (1~5V)
011: 2 NPN+Analog (Current) output (4~20mA)
02: 2 NPN+Copy function
030: 2 PNP+Analog (Voltage) output (1~5V)
031: 2 PNP+Analog (Current) output (4~20mA)
04: 2 PNP+Copy function


Pressure Port
F1: R1/8", M5
F2: NPT1/8", #10-32UNF
F3: G1/8" (BSPP), M5

Optional Parts
MP-A12: Mounting bracket (BT-12)
MP-A13: Mounting bracket (BT-13)
MP-B2: Panel adapter (PA-C)
MP-C2: Panel adapter + Front protective lid (PA-D)


D. PANEL DESCRIPTION




E. DIMENSIONS



F. OPTIONAL PARTS DIMENSIONS




G. INITIAL SETTING MODE




[NOTE:]
*1. This setting mode will not display when output 2 is set to off.
*2. Pressure unit is kPa by positive & pressure unit is kPa by vacuum and compound.
*3. Only applicable for Vacuum/Compound.

J. PRESSURE SETTING MODE




[NOTE:]
1. In case hysteresis is set at less than or equal to 2 digits, switch output may be after input pressure fluctuates near the set point.
2. When using window comparator mode, the difference between two set points must be greater than the fixed hysteresis, otherwise will cause the switch output to malfunction.

K. OUTPUT TYPE




[NOTE:]
*1. In case hysteresis is set at less than or equal to 2 digits, switch output may be after input pressure fluctuates near the set point.
*2. When using window comparator mode, the difference between two set points must be greater than the fixed hysteresis, otherwise will cause the switch output to malfunction.

L. ANALOG OUTPUT DESCRIPTION




M. ZERO POINT SETTING




[NOTE:]
Do not disconnect power when the sub-display and setting value is flashing alternately, otherwise the system cannot store the values.

P. COPY FUNCTION SETTING



[NOTE:]
*1. If turn on power is not synchronization, the data cannot be copied.
*2. When the data copy fails, please confirm the wire connection.
*3. Only for MP43C-02 and MP43C-04 can have this setting selection.

Q. FINE ADJUSTMENT MODE



[NOTE:]
1. setting resolution is 0.1% R.D.
2. The signal would be changed with analog output after adjusting.

R. ERROR CODE INSTRUCTION

Error Code	Instruction
Err1	Output 1 load current more than 125mA
Err2	Output 2 load current more than 125mA
Err3	Output 3 load current more than 125mA
Err4	Output 4 load current more than 125mA
Err5	Output 5 load current more than 125mA
Err6	Output 6 load current more than 125mA
Err7	Output 7 load current more than 125mA
Err8	Output 8 load current more than 125mA
Err9	Output 9 load current more than 125mA
Err10	Output 10 load current more than 125mA
Err11	Output 11 load current more than 125mA
Err12	Output 12 load current more than 125mA
Err13	Output 13 load current more than 125mA
Err14	Output 14 load current more than 125mA
Err15	Output 15 load current more than 125mA
Err16	Output 16 load current more than 125mA
Err17	Output 17 load current more than 125mA
Err18	Output 18 load current more than 125mA
Err19	Output 19 load current more than 125mA
Err20	Output 20 load current more than 125mA

S. PRESSURE UNIT CONVERSION TABLE

Unit	MPa	kPa	bar	psi	inHg	mmHg
MPa	1	100	10	145.038	750.061	760.0
kPa	0.01	1	0.01	0.145038	0.750061	0.760
bar	0.1	100	1	14.5038	7.50061	7.60
psi	0.006895	6.895	0.070308	1	2.03602	2.03602
inHg	0.000334	0.334	0.003453	0.070308	1	2.54
mmHg	0.000133	0.133	0.001359	0.027611	0.0254	1