


ATmega328

PCINT15/RESET	1	28	ADC5/SCL/PCINT13
PCINT16/RXD	2	27	ADC4/SDA/PCINT12
PCINT17/TXD	3	26	ADC3/PCINT11
PCINT18/INT0	4	25	ADC2/PCINT10
PCINT19/OC2B/INT1	5	24	ADC1/PCINT9
PCINT20/XCK/T0	6	23	ADC0/PCINT8
VCC	7	22	GND
GND	8	21	AREF
PCINT6/XTAL1/OSC1	9	20	AVCC
PCINT7/XTAL2/OSC2	10	19	SCK/PCINT5
PCINT21/OC0B/T11	11	18	MISO/PCINT4
PCINT22/OC0A/AIN0	12	17	MIS/OC2A/PCINT3
PCINT23/AIN1	13	16	SS/OC1B/PCINT2
PCINT0/CLK0/ICP1	14	15	OC1A/PCINT2



INTER CONNECTION BETWEEN ARDUINO BOARD & IC ATMEGA-328

(By Mr Adeeb Raza)